

AT-1279 Cinemeccanica Analog Reader Installation Instructions

Basic Installation Procedure

- Step 1) Remove outer Sound Drum Bell and set aside.
- Step 2) Remove existing Solar Cell assembly.

SAVE SCREWS FOR REUSE

Step 3) Remove existing Exciter Lamp and Sound Lens assembly from its' Mounting Bracket.

SAVE SCREW AND WASHERFOR REUSE

- Step 4) Using screws saved in Step 2. Mount new LED Assembly in place of the old Solar Cell Bracket.
- Step 5) Using screwsaved in Step 3. Mount the new Solar Cell Reader assembly in place of the old Exciter Lamp and Sound Lens assembly. Mount new Bracket in place and then thighten lower set screw just enough to reomve any loosness between Backet and mounting Bracket.
- Step 6) Reinstall the Outer Sound Drum Bell.
- Step 7) Center the LED to the Sound Track by loosening the (1) screws on the LED Post and move the LED in or out to center on the sound track.

FOR FINAL ADJUSTMENT REFER TO AT-1200 INSTRUCTION MANUAL